

Mennen Arena

Scoreboard Operating Instructions

Start-Up

- Turn the Power Switch **On**.
- At the **Resume Game? Y/N** prompt:
 - Press **<Enter/Yes>** to resume the game where last shut off. Or
 - Press **<Clear/NO>** to start a new game

Team Score

- **<Score+1>** and **<Score-1>** increment and decrement the team score

Time Out

- The first press of **<TIME OUT>** displays the number of full time outs for the selected team. The second press displays the number of partial timeouts (if applicable.) Press enter to take a time out for the selected team.
- The **<TIME OUT ON/OFF>** selects a full (1st press) or partial (2nd press) time out and starts the time out clock.
- The time out clock may be displayed on the main scoreboard using the **Time Outs Show on Main** setting in the **Menu** under **Edit Settings**.

Period

- **<PERIOD+1>** increments the current period number.

Shots on Goal

- **<SHOTS ON GOAL+1>** and **<SHOTS ON GOAL-1>** increment and decrement the team shots on goal.

Saves

- **<SAVES+1>** and **<SAVES-1>** increment and decrement the team goalie saves.

Penalty

- **<PENALTY>** turns the penalty indicators on or off for the selected team.
- **<PLAYER PENALTY>** sets the player number and penalty time for the selected team.
- **<MAJOR PENALTY>**, **<MINOR PENALTY>** deletes a player-penalty time. Each press scrolls through the list of player and penalty times for the selected team.
- **<CLEAR ALL PENALTIES>** deletes all player-penalty times for the selected team.
- **<ENABLE PENALTY CLOCKS>** and **<DISABLE PENALTY CLOCKS>** control the automatic decrement of the penalty clocks with the main clock. The current status is shown as an **EN** or **DS** in the bottom right corner of the LCD screen.

Edit Key Function

- Press **<EDIT>** followed by any of the following keys to edit the respective value **<SCORE+1>**, **<SCORE-1>**, **<SHOTS ON GOAL+1>**, **<SHOTS ON GOAL-1>**, **<SAVES+1>**, **<SAVES-1>**, **<PERIOD+1>**, **<TIME OUT ON/OFF>**, **<TIME OUT>**